

INSTRUCTIONS ADDITIONNELLES

UTILISATION EN MODE PUBLIC

Plusieurs personnes peuvent utiliser le même casier à tour de rôle avec un code paramétré par chaque utilisateur. Le dernier utilisateur doit impérativement laisser la serrure ouverte pour que le suivant puisse paramétrer son propre code.

IMPORTANT : le réglage d'usine est mode public. Pour passer à l'utilisation en mode privé, suivre les instructions du paragraphe. Le paramétrage s'effectue avec la porte ouverte.

PARAMETRAGE DU CODE PERSONNEL

Positionner la flèche du sélecteur sur « CHANGE »



Paramétrer votre code personnel (exemple : 2017)



Positionner la flèche du sélecteur sur « CLOSE »



Cachez le code en tournant les 4 chiffres vers une combinaison différente

LA PORTE EST FERMÉE, VOUS NE CONNAISSEZ PAS LE CODE, COMMENT L'OUVRIR :

1. Insérer la clé (passe) et faire un 1/2 tour vers la droite
2. tourner chaque chiffre jusqu'à son blocage
3. tournez la clé d'1/2 tour vers la gauche
4. retirer la clé
5. tourner le bouton et ouvrir la porte.

UTILISATION EN MODE PRIVE

1 seule personne a accès à son casier grâce à un code paramétré par lui-même.

IMPORTANT : le paramétrage du code personnel s'effectue avec la porte ouverte.

PARAMETRAGE DU CODE PRIVE

Positionner la flèche du sélecteur sur « OPEN »



Positionner le curseur arrière sur la position « 3. CODE RESET »




Positionner la flèche du sélecteur sur « CHANGE » et paramétrer votre code personnel (exemple : 2017)



Positionner la flèche du sélecteur sur « CLOSE »



Positionner le curseur arrière sur la position « 1. PERSONAL »



Positionner la flèche du sélecteur sur « OPEN »



Si vous souhaitez reparamétrer un nouveau code, réitérer la même opération.

ADDITIONAL INSTRUCTIONS

PERSONAL CODE SETTING

Several people can use the same locker in turn, with a code set by each user. The last user must leave the lock open so that the next user can set a new code.

IMPORTANT: The factory setting is public mode. To switch to use in private mode, follow the instructions in the paragraph. The code must be set at door open.

USE IN PUBLIC MODE

Position the arrow of the selector on "CHANGE"



Set your personal code (example: 2017)



Position the arrow of the selector on "CLOSE"



Hide the code by turning the 4 digits to a different combination

THE DOOR IS CLOSED, YOU DON'T KNOW THE CODE, HERE IS HOW TO OPEN IT:

1. Insert the key (pass) and make a 1/2 turn to the right
2. turn each number until it locks
3. turn the key 1/2 turn to the left
4. remove the key
5. turn the knob and open the door.

PRIVATE CODE SETTING

Only 1 person has access to a locker thanks to a personal code set up by himself.

IMPORTANT: the personal code must be set at door open.

USE IN PRIVATE MODE

Position the arrow of the selector on "OPEN"



Position the back cursor on the position "3. CODE RESET"



Position the selector arrow on "CHANGE" and set your personal code (example: 2017)



Position the arrow of the selector on "CLOSE"



Position the back cursor on the position "1. PERSONAL"



Position the arrow of the selector on "OPEN"



If you wish to set a new code, repeat the same operation.